

# **TC1920**

## **Telephone/Analog Extender over Ethernet (10/100Base-T)**

**User Manual**  
**MNL-19200-01-03**



TC Communications, Inc. 17881 Cartwright Road - Irvine, CA 92614

Tel: (949) 852-1972 Fax: (949) 852-1948 Web Site: [www.tccomm.com](http://www.tccomm.com) Email: [sales@tccomm.com](mailto:sales@tccomm.com)

---

All Rights Reserved

Copyright 2021 by TC Communications. Products described in this publication are protected by one or more U.S. and foreign patents.

## Trademarks

The TC Communications logo is a registered trademark.

JumboSwitch is a registered trademark of TC Communications.

Other product and brand names may be trademarks or registered trademarks of their respective owners.

## Documentation Disclaimer

This document is provided “as-is” and is to be used only as a general guide. TC Communications disclaims all warranties, express or implied, regarding the accuracy of the information. TC Communications shall not be liable for any indirect, special, incidental, or consequential damages (including damages for loss of business, loss of profits, loss of business information, business interruption or other pecuniary loss) arising out of errors in this document.

The information given in this document is reviewed regularly and any necessary corrections will be included in subsequent editions. We appreciate any suggested improvements. We reserve the right to make technical improvements without notice.

Dissemination or reproduction of this document, or evaluation and communication of its contents, is not authorized except where expressly permitted. Violations are liable for damages. All rights reserved, particularly for the purposes of patent application or trademark registration. This document contains proprietary information, which is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced or translated to another language without the prior written consent of TC Communications.

# Record of Revisions

Revision	Date	Description of Changes
1.1	04/20/2018	Initial Release.
1.2	09/01/2020	Firmware version update. LED definition update
1.3	06/18/2021	Feature update.

TC Communications  
17881 Cartwright Road  
Irvine, California U.S.A. 92614  
Tel. (949) 852-1972  
Fax (949) 852-1948

Website: [tccomm.com](http://tccomm.com)

---

## Guide to Alert Symbols

These alert symbols are used in Caution, Warning, and Danger notes.

Symbol	Meaning
	Pinching or crushing hazard.
	Electrical hazard.
	Equipment alert: be careful of damage from static electricity.
	A general alert: used for all other hazardous conditions (referring to people, not equipment).

---

## Guide to Safety Notes

---

### Important

*Important* is used for information that helps you:

- Handle equipment efficiently
  - Avoid losing work in a software program
  - Increase reliability
- 

### Notice

*Notice* is used for information that helps you prevent damage to equipment.

---

### Notice



*Notice* with the static electricity alert symbol is used for information that helps you prevent damage to equipment from static electricity.

---

### Caution



*Caution* is used to alert you to a possible hazard which could cause a minor injury.

Caution notes include an alert symbol, such as this general alert.

---

### Warning



*Warning* is used to alert you to a possible hazard which **could** cause a serious injury or even death.

Warning notes include an alert symbol, such as this pinching hazard alert, indicating that there is a serious pinching or crushing hazard.

---

### Danger



*Danger* is used to alert you to an imminent hazard which, if not avoided, **will** result in death or serious injury.

This word is reserved for only the most extreme conditions, when following procedures correctly is a matter of life or death. *Danger* is used especially for conditions where there are limited safeguards in place.

Danger notes include an alert symbol, such as this electrical hazard alert, indicating that there is danger of severe shock or electrocution.

---

# TABLE OF CONTENTS

---

## 1 Introduction

1.1	General Information . . . . .	1-1
1.2	Product Description . . . . .	1-1
1.2.1	Front and Back Panels . . . . .	1-1
1.2.2	Hardware . . . . .	1-2
1.2.3	Features . . . . .	1-3
1.2.4	Applications. . . . .	1-3
1.2.5	Compliance. . . . .	1-5
1.2.6	Environment . . . . .	1-5
1.2.7	Administration and Management . . . . .	1-5
1.2.8	Power . . . . .	1-5
1.3	Specifications . . . . .	1-6
1.3.1	Default Software Configuration. . . . .	1-7
1.3.2	Environmental & EMI Compliance . . . . .	1-8

## 2 Installation

2.1	Unpacking . . . . .	2-1
2.2	Equipment Location . . . . .	2-1
2.3	Power Supply . . . . .	2-1
2.4	Dry Contact Alarm Relay (DCAR) . . . . .	2-2
2.5	System Start Up . . . . .	2-2
2.6	System Configuration. . . . .	2-3
2.6.1	TC1920 Front Panel . . . . .	2-3
2.6.2	TC1920 Rear Panel . . . . .	2-5
2.7	Unit Power . . . . .	2-5
2.7.1	Turning on the unit . . . . .	2-5
2.8	Cabling. . . . .	2-5
2.8.1	Console Port . . . . .	2-6
2.8.2	Telephone/Analog Port . . . . .	2-7
2.8.3	FastEthernet Ports . . . . .	2-7

## 3 Quick Start Guide

3.1	Introduction. . . . .	3-1
3.2	Master/Slave Pairing Modes . . . . .	3-1
3.2.1	Master Presets . . . . .	3-1
3.2.2	Slave Presets . . . . .	3-1
3.3	Procedure. . . . .	3-2
3.4	Setup and Configuration Verification . . . . .	3-2

## 4 Management through the Web

4.1	Introduction. . . . .	4-1
4.2	Setup . . . . .	4-1
4.3	Screens . . . . .	4-2
4.3.1	Overview. . . . .	4-3
4.3.2	System Settings . . . . .	4-5
4.3.3	IP Settings. . . . .	4-7
4.3.4	Unit Alarm. . . . .	4-7
4.3.5	Advanced . . . . .	4-11

# TABLE OF CONTENTS

---

4.3.6	Telephone/Analog . . . . .	4-17
-------	----------------------------	------

## 5 Troubleshooting

5.1	Introduction . . . . .	5-1
5.2	Strategy for Troubleshooting . . . . .	5-1
5.2.1	Common Problems . . . . .	5-2
5.3	Mechanical . . . . .	5-3
5.3.1	Environment . . . . .	5-3
5.3.2	Cabling . . . . .	5-3
5.4	Electrical . . . . .	5-5
5.4.1	Using Front Panel Indicator LEDs For Diagnostics . . . . .	5-5
5.4.2	Power Supplies . . . . .	5-11
5.5	Software . . . . .	5-12
5.5.1	Default Software Configuration . . . . .	5-12
5.5.2	Resolving Software Problems . . . . .	5-13

## Appendix A Return Policy

A.1	Return Policy . . . . .	A-1
A.1.1	Warranty . . . . .	A-1
A.1.2	Limitation of Liability . . . . .	A-2

## Appendix B Safety

B.1	Overview . . . . .	B-1
B.2	Certified Usage . . . . .	B-1
B.2.1	Qualification Requirements for Personnel . . . . .	B-1
B.2.2	National and International Safety Regulations . . . . .	B-1
B.2.3	Recycling . . . . .	B-2
B.3	Power Supply . . . . .	B-2
B.4	Environment . . . . .	B-3

## 1.1 General Information

This manual is intended to describe the features and functionality in addition to aiding in the planning, configuring, commissioning, and maintaining of the TC1920 Telephone/Analog over IP extender.

## 1.2 Product Description


The TC1920 Ethernet Telephone/Analog Extender enables telephone service over an Ethernet network via 10/100Base-T connections. It has built-in codecs that digitize voice and converts to packets for transmission between local and remote TC1920s, with designated IP addresses, as well as other SIP-based Voice over IP (VoIP) devices. It is compatible with PBX and Key Systems (POTS).

LAN connections can be made by most types of Full Duplex Ethernet devices, including switches, routers, bridges, transceivers, etc. A web-based management user interface is provided monitoring, maintenance, and configuration of the unit.

### 1.2.1 Front and Back Panels



Figure 1-1 TC1920 Front Panel



**Figure 1-2 TC1920 Back Panel**

## 1.2.2 Hardware

This card has the following:

- Serial Console port
- Two FastEthernet ports
- One FXS port
- One Dry Contact relay
- Temperature Options (-20°C to +70°C or -40°C to +80°C)

### 1.2.3 Features

The TC1920 is a complete telephony solution to address customer communications needs. By simply connecting to your existing LAN, you have added the flexibility of a phone system in even your most remote location.

- The TC1920 Telephone/Analog over IP is a complete call processing center in a compact package with no central hub required.
- Compatible with analog phones, the TC1920 is able to utilize QoS prioritization to guarantee toll quality voice regardless of network traffic or congestion.
- Although TC1920 is designed for the LAN environments often found in the industrial automation arena, but it could also work over the Internet, preferably in a VPN setting to have better voice quality.


This card has the following features:

- Master/Slave Mode for Quick Start
- Internal Address Book or SIP Server
- Hot Link with Heartbeat
- Group Hunting or Dialing
- Volume Control, Mute
- Caller ID
- Echo Cancellation (ITU-T G.168)
- Fax support (T.38)
- SRTP and TLS


### 1.2.4 Applications

The TC1920 is intended to provide reliable telephone/analog service over Ethernet networks. It is often used as critical phone links in a campus environment such as:

1. Utility Substation Networks.
2. Airport service stations
3. Rail side maintenance stations
4. Highway roadside phones
5. Military compound
6. Parking lot entrance



**Figure 1-3 Typical Application Using TC1920s to Extend Telephone Service via an Ethernet Network in a Substation Environment**



**Figure 1-4 Typical Application Using TC1920s to Provide Hotlink Service to Multiple Remote Locations**

## 1.2.5 Compliance

This card complies with the following standards:

- IEEE 802.3 and 802.3u
- Compliant with SIP
- Compliant with SDP
- Media support: RTP Control Protocol
- Codecs supported:
  - G.711  $\mu$ -Law/A-Law
  - G.726-32, G.726-16
  - G.729A
  - T.38
- IEC 61850-3
- IEEE 1613 and NEMA TS-2

## 1.2.6 Environment

The standard operating temperature of the card falls within most environmental conditions (i.e. -20°C to +70°C). However, the TC1920 is also offered with an extreme temperature option for harsher conditions (i.e. -40°C to +80°C). There is no cooling fan or filtering devices.

## 1.2.7 Administration and Management

The TC1920 can be remotely managed through the following features:

- Web-based graphical user interface (WebUI)

## 1.2.8 Power

There are several power supply options available. See [Power](#), on page 1-5.

- The power supply comes with the unit.
- Internal sensor determine the type of power supply installed and adjusts the unit automatically.
- LEDs indicate if power is present.

---

**NOTE**

The dual load-sharing power supplies feature automatically switches over in the event of a power failure.

---

## 1.3 Specifications

<b>Data Rates</b>	
Ethernet	10/100 Mbps

<b>Capacity</b>	
Ethernet	2 back ports
Telephone/Analog	1-FXS

<b>Telephone/Analog</b>	
FXS Connectors	RJ-11

<b>Ethernet</b>	
Ethernet Standards	IEEE 802.3, 802.3u
Ethernet Connectors	RJ-45

<b>Visual Indicators</b>	
System LEDs	PWR A/B, Vcc, RDY, Alarm, Link, BP1, BP2
Ethernet LED	Link, Dup
Phone LEDs	Ring, Hook

<b>Power Supply Type</b>	<b>Input Range</b>		<b>Power Consumption</b>
	<b>Min</b>	<b>Max</b>	
12 VDC	10 VDC	18 VDC	< 10W
24 VDC	18 VDC	36 VDC	
-48 VDC	36 VDC	72 VDC	

<b>General Data</b>	
Weight	(0.43 kg) 0.95 lbs

<b>Physical Dimensions</b>	
Height	(3.15 cm) 1.24 inches
Width	(17.68 cm) 6.96 inches
Depth	(22.61 cm) 8.90 inches

### 1.3.1 Default Software Configuration

<b>Network Management (WebUI)</b>	
Configuration	Default
IP Address	192.168.1.1 (Master) 192.168.1.2 (Slave)
Subnet Mask	255.255.255.0
Gateway IP	0.0.0.0
Username	admin
Password	admin

<b>Telephone/Analog</b>		
Configuration	Options	Default
SIP Option	SIP Server, Address Book	Address Book
Codecs	G.711 $\mu$ -Law, G.711 A-Law, G.726-32, G.716-16, G.729A	G.711 $\mu$ -Law, G.711 A-Law, G.726-32, G.726-16, G.729A

## 1.3.2 Environmental & EMI Compliance

	Test	Industrial Standards	TC Communications - JumboSwitch Type Test and Levels	
			Power Supply Unit (PSU)	RJ-45 & Signal
Temperature/Humidity	Low Temperature Use	IEC 61850-3, IEEE 1613, NEMA TS-2	IEC 60068-2-1; Ae; -40°C; 16 hour	
	Low Temperature Storage	IEC 61850-3, IEEE 1613, NEMA TS-2		
	High Temperature Use	IEC 61850-3, IEEE 1613, NEMA TS-2	IEC 60068-2-2; Be; +80°C; 16 hour	
	High Temperature Storage	IEC 61850-3, IEEE 1613, NEMA TS-2	IEC 60068-2-2; Bd; +85°C; 16 hour	
	Damp Heat	IEC 61850-3, IEEE 1613, NEMA TS-2	IEC 60068-2-30; Db; +55°C; 95%; 96 hours	
Mechanical	Vibration	IEC 61850-3, IEEE 1613, NEMA TS-2	IEC 60068-2-6; Fc; 3 - 150 Hz; 7.5 mm; 2 g; 10 sweeps per axis	
	Shock	IEC 61850-3, IEEE 1613, NEMA TS-2	IEC 60068-2-27; Ea; 30g; 11ms	
ElectroMagnetic Compatibility	Electrostatic Discharge Immunity	IEEE 1613	IEC 61000-4-2; 8kV contact; 15 kV air	
	Radiated RF Immunity	IEC 61850-3, IEEE 1613	IEC 61000-4-3; 80 MHz - 2000 MHz; 10 V/m; AM 80% 1 kHz	
	EFT/Burst Immunity	IEC 61850-3, IEEE 1613	IEC 61000-4-4; 4 kV CM; TM	IEC 61000-4-4; 4 kV CM; TM
	Surge Immunity	IEC 61850-3	IEC 61000-4-5; 4 kV LG; 2 kV LL	IEC 61000-4-5; 4 kV LG; 2 kV LL
	Conducted RF immunity	IEC 61850-3	IEC 61000-4-6; 150 kHz - 80 MHz; 10 V; AM 80% 1 kHz	IEC 61000-4-6; 150 kHz - 80 MHz; 10 V; AM 80% 1 kHz
	Magnetic Field Immunity	IEC 61850-3	IEC 61000-4-8; 50 Hz; 100 A/m cont.; 1000 A/m 1 s	
	Damped Oscillatory Magnetic Field Immunity	IEC 61850-3	IEC 61000-4-10; 100 kHz; 30 A/m	
	Damped Oscillatory Magnetic Field Immunity	IEC 61850-3	IEC 61000-4-10; 1 MHz; 30 A/m	
Power Supply Unit (PSU) Variations	AC Voltage Dips	IEC 61850-3	IEC 61000-4-11; 30% & 100%, 0.5s	NA
	DC Voltage Dips	IEC 61850-3	IEC 61000-4-29; 40% & 70%, 0.1s	NA
	Damped Oscillatory Wave	IEC 61850-3	IEC 61000-4-12; 2.5 kV CM, 1.0 kV DM @1MHz	IEC 61000-4-12; 2.5 kV CM, 1.0 kV DM @ 1MHz
	Conducted PF CM Voltage	IEC 61850-3	IEC 61000-4-16; 50 Hz; 30 V cont.; 300 V 1s	IEC 61000-4-16; 50 Hz; 30 V cont.; 300 V 1s
	Conducted Emission	IEC 61850-3	CE/FCC/CISPR22 class A	CE/FCC/CISPR22 class A
	Radiated Emission	IEC 61850-3	CE/FCC/CISPR22 class A	
Dielectric	Dielectric 50 Hz Test	IEEE 1613	IEC 60255-5; 2 kV	IEC 60255-5; 0.5 kV
	Impulse Voltage Test	IEEE 1613	IEC60255-5; 5 kV	IEC 60255-5; 5 kV

## 2.1 Unpacking

Before unpacking any equipment:

- Inspect all shipping containers for evidence of external damage caused during transportation
- Inspect for damage after it is removed from the containers

### IMPORTANT



Any claims concerning shipping damage should be made directly to the pertinent shipping agencies. Any discrepancies should be reported immediately to the Customer Service Department at TC Communications, Inc. at (949) 852-1973.

## 2.2 Equipment Location

The TC1920 should be located in an area that provides adequate light, work space and ventilation.

### IMPORTANT




Avoid locating it next to any equipment that may produce electrical interference or strong magnetic fields, such as elevator shafts or heavy duty power supplies.

As with any electronic equipment, keep the unit from excessive moisture, heat, vibration and freezing temperatures.

## 2.3 Power Supply

The TC1920 can be powered by an external DC power adapter rated 12 VDC @300mA. There are two terminal block connectors labeled "PWR A" and "PWR B" only one is required to power up the unit. Since each TC1920 card is equipped with a power redundancy capability, the power LEDs on the front panel will light according to which power jack (A or B) is connected. Both LEDs will light when power redundancy is utilized.



### IMPORTANT



Read and only connect a supply voltage that corresponds to the type plate of your device. Make sure that the contact load capacity of the signal contact is not exceeded.

## 2.4 Dry Contact Alarm Relay (DCAR)

A terminal block connector at the rear panel provides for the Dry Contact Alarm Relay. This relay can be used in NO (Normal Open) or NC (Normal Close) configuration.

When used in NO (Normal Open) configuration, the relay will close if the unit loses power completely or the Alarm is on. The relay remains open during normal operation.

When used in NC (Normal Close) configuration, the relay will open if the unit loses power completely or the Alarm is on. The relay remains close during normal operation.

## 2.5 System Start Up

Apply the power by plugging the power plug into a power jack (both PWR A & PWR B for dual power units).

After power is applied, all LEDs (except PWR & VCC LEDs) will flash momentarily and the following LED status should be observed from the front and back panels:

1. The Power "A" and/or "B" and VCC LEDs should be lit.
2. The "FXS" LED will be solid on.
3. The "LINK" LED of the Ethernet ports on the back panel will be on or flashing indicating that the Ethernet connection is established. This is normal when an Ethernet cable is connected to an Ethernet port.

## 2.6 System Configuration

The TC1920 has been pre-tested and switches have been set per factory specifications. Refer to [5.4.1 Using Front Panel Indicator LEDs For Diagnostics](#), on page 5-5 for detailed LED descriptions.

### 2.6.1 TC1920 Front Panel





Figure 2-1 TC1920 Front Panel

### 2.6.1.1 Front Panel DIP Switch Functions



**Figure 2-2 Front Panel Dip Switch**

The DIP Switch functions on the TC1920 are described below.

- **MSTR/SLVE** selects the default pairing mode. Up position sets Master and down position sets Slave.

**NOTE**

The selected mode will only be used when unit is restored to default. The default settings may not be used if configuration changes are made through the user interface.

## 2.6.2 TC1920 Rear Panel




Figure 2-3 TC1920 Rear Panel

## 2.7 Unit Power

### 2.7.1 Turning on the unit

After powering up the unit, there will be thirty seconds of internal circuit testing.

## 2.8 Cabling

The TC1920 has 4 ports on the back panel:

- 1x Telephone/Analog port
- 1x RJ-45 9600-baud serial console port
- 2x FastEthernet ports


## 2.8.1 Console Port

This port allows you to manage the unit through CLI using a RS-232 serial interface.



### Console Cable RJ-45 Pin Assignment

1 - N/A
2 - N/A
3 - Tx
4 - GND
5 - GND
6 - Rx
7 - N/A
8 - N/A



### Serial Console Port Specifications

Baud Rate	9600 bps
Databits	8
Parity	None
Stopbits	1
Flow Control	None

## 2.8.2 Telephone/Analog Port

This port is used to connect to end devices (FXS).


FXS Port RJ-11 Pin Assignment	
1 - N/A	 <p>The diagram shows an RJ-11 jack with six pins. The pins are numbered 1 through 6 from right to left. Pin 1 is the top-right pin, pin 2 is the second from the right, pin 3 is the middle pin, pin 4 is the second from the left, pin 5 is the middle-left pin, and pin 6 is the bottom-left pin.</p>
2 - N/A	
3 - Ring	
4 - Tip	
5 - N/A	
6 - N/A	

Figure 2-4 RJ-11 Pin Assignments

## 2.8.3 FastEthernet Ports

These ports are used for management and connecting to the Ethernet network.


Ethernet Port RJ-45 Pin Assignment	
1 - Output, Tx+	 <p>The diagram shows an RJ-45 jack with eight pins. The pins are numbered 1 through 8 from right to left. Pin 1 is the top-right pin, pin 2 is the second from the right, pin 3 is the middle-right pin, pin 4 is the middle-left pin, pin 5 is the second from the left, pin 6 is the middle-left pin, pin 7 is the second from the left, and pin 8 is the bottom-left pin.</p>
2 - Output, Tx-	
3 - Input, Rx+	
4 - N/A	
5 - N/A	
6 - Input, Rx-	
7 - N/A	
8 - N/A	

Figure 2-5 RJ-45 Pin Assignments



## 3.1 Introduction

The TC1920 is designed for quick and easy installation and validation. After the mechanical installation (see [2.3 Power Supply, on page 2-1](#)), this quick-start chapter describes how to perform the TC1920 initial setup in a basic network application.

## 3.2 Master/Slave Pairing Modes

As a quick and easy tool to setup and validate the TC1920 on a LAN, the Master and Slave pairing modes were created.

Each mode consists of preset configurations that allow two units to be quickly setup to paired and operating with one another immediately after boot-up.

Once boot-up has completed, LEDs should indicate that the units have linked with each other. At this point calls can be made between the two units. If the units indicate link and calls can be made, then this is a quick validation that the network is able to support the TC1920.

### 3.2.1 Master Presets

The following are the basic presets for a unit in Master mode.

IP Address:	192.168.1.1
Subnet Mask:	255.255.255.0
Phone Number:	101
Hotlink Number:	201

### 3.2.2 Slave Presets

The following are the basic presets for a unit in Master mode.

IP Address:	192.168.1.2
Subnet Mask:	255.255.255.0
Phone Number:	201
Hotlink Number:	101

### 3.3 Procedure

This section will guide you through the basic setup and initialization for a pair of TC1920 units.

#### NOTE

The following procedure assumes that the units have been restored to default, and are running factory default settings.

#### To install and setup the units

1. Set Unit #1 as Master by setting dip switch 1 to MSTR (up position). Set Unit #2 as Slave by setting dip switch 2 to SLVE (down position).
2. Power up both units.
3. After booting is complete, each unit should be running at their respective default pairing modes (as set by the dip switches).

### 3.4 Setup and Configuration Verification

The following procedure helps you determine if there are any corrections to be made to the setup.

#### To verify the unit installation

1. Connect the TC1920 units' P1 ports together through an Ethernet connection with phone stations connected to TC1920 Phone/Line ports.
2. The BP1 LEDs of each unit should turn on and flash occasionally.
3. After a few seconds, the unit should indicate that their are linked with one another.
4. Check the following LEDs to verify both units are operating properly:

RDY	Solid ON
LINK	Solid ON
FXS	Solid ON
MSTR	Solid ON (Unit 1 Master)
SLVE	Solid ON (Unit 1 Slave)
HT-L	Solid ON

5. FXS ports will perform a quick ring test after initialization has completed.



**Figure 3-1 TC1920 Master (Top) & Slave (Bottom) Units**

# Chapter 4 Management through the Web

## 4.1 Introduction

TC Communications' web-based management is an integrated, user-friendly interface on-board the unit. This interface can be accessed through the Ethernet Port on the back of the unit, or over your IP network.

The web interface can be accessed remotely over your IP network if the unit has been integrated with your local area network using standard Ethernet cabling.

This reference chapter defines each page's status, configurations, and describes the parameters of the options you can choose.

### NOTE

WebUI is supported on the following web browsers:

- Google Chrome
- Mozilla Firefox 4 or later
- Microsoft Edge
- Microsoft Internet Explorer 9 or later
- Apple Safari

## 4.2 Setup

Connect by typing the IP address assigned to the interface card into a web browser's address field. Setup, diagnostics, and management is accessible via HTTP.

### To connect a PC

1. Using a CAT-5E or CAT-6 cable, connect the PC to the Ethernet port or any Ethernet port on the JumboSwitch® network
2. Access the PC web browser and enter the TC1920 IP address.
3. Login with default username "*admin*" and password "*admin*" or use the password and user name assigned to you by the administrator.

## 4.3 Screens

This reference section defines each screen in TC1920 and describes the parameters of the options you can choose with descriptions of the configurations. The Navigation Menu and section tabs provide access the screens that operate the unit. This section begins with a chart that shows the order in which each screen or page appears.

### Web Management Page

*System Settings*, on page 4-5

*System Time*, on page 4-6

*IP Settings*, on page 4-7

*Unit Alarm*, on page 4-7

*Advanced*, on page 4-11

*About*, on page 4-12

*Configuration File*, on page 4-13

*Users*, on page 4-14

*Reboot*, on page 4-14

*Restore Defaults*, on page 4-15

*Firmware*, on page 4-16

*Telephone/Analog*, on page 4-17

*Telephone/Analog > Status*, on page 4-17

*Telephone/Analog > General Settings*, on page 4-20

*Telephone/Analog > Address Book*, on page 4-26

*Telephone/Analog > Dial Features*, on page 4-30

*Telephone/Analog > Codecs*, on page 4-33

*Telephone/Analog > Call Features*, on page 4-36

*Telephone/Analog > Security*, on page 4-39

*Telephone/Analog > Tones*, on page 4-42

### 4.3.1 Overview

Features and options associated with the TC1920 are located in the menu area on the left side of the web page display. This area displays breadcrumb style information of the current option selected and other available options.

The home page displays summary information of the TC1920. The Settings tab allows for basic settings to be configured.

**Summary**

---

Status Settings

<b>System Uptime:</b>	0 Days 8 Hours 13 Minutes 5 Seconds
<b>Unit Alarm:</b>	Off
<b>Ethernet Back Port 1:</b>	100 Mbps / Full
<b>Ethernet Back Port 2:</b>	100 Mbps / Full
<b>Pairing Mode:</b>	Master

---

Telephone/Analog

<b>Heartbeat:</b>	Sync
<b>Call Status:</b>	Not in Use
<b>Ring:</b>	
<b>Hook:</b>	
<b>Compression Rate:</b>	No call in progress

---

Local

<b>Interface:</b>	FXS
<b>Description:</b>	Not Configured
<b>Receiving Port:</b>	5060
<b>Physical (MAC) Address:</b>	00:19:20:00:25:67
<b>IPv4 Address:</b>	192.168.1.1
<b>IPv4 Subnet Mask:</b>	255.255.255.0
<b>IPv4 Default Gateway:</b>	Not Configured

---

Remote

<b>Description:</b>	Not Configured
<b>IPv4 Address:</b>	192.168.1.2
<b>Sending Port:</b>	5060

---

Refresh

**Figure 4-1 Summary Status**

## Summary

Status	Settings
<b>Pairing Mode:</b>	Master ▾
<b>IP Settings</b>	
<b>IPv4 Address:</b>	192 . 168 . 1 . 1
<b>IPv4 Subnet Mask:</b>	255 . 255 . 255 . 0
<b>IPv4 Default Gateway:</b>	0 . 0 . 0 . 0
<b>Domain Name Server</b>	
<b>Primary DNS Server:</b>	0 . 0 . 0 . 0
<b>Secondary DNS Server:</b>	0 . 0 . 0 . 0
<b>Telephone/Analog</b>	
<b>Receiving Port (1 ~ 65535):</b>	5060
<b>Local</b>	
<b>Description:</b>	
<b>Compression Rate (CP-R):</b>	Auto-negotiate best quality ▾
<b>Alarm Relay:</b>	<input type="checkbox"/> On Unit Alarm <input type="checkbox"/> On Ring
<b>Remote</b>	
<b>IPv4 Address:</b>	192 . 168 . 1 . 2
<b>Sending Port (1 ~ 65535):</b>	5060
<b>Description:</b>	
<input type="button" value="Apply"/> <input type="button" value="Save"/> <input type="button" value="Refresh"/>	

**Figure 4-2 Summary Settings**

## 4.3.2 System Settings

This section provides general system-wide settings.

### Information

This page allows the system administrator to customize the definitions so that the unit can be readily identified when managing the unit.

General Settings

---

Information    System Time

---

**Name:**

**Location:**

**Contact:**

**Description #1:**

**Description #2:**

**Description #3:**

---

**Figure 4-3 System Information**

Name	Label of unit
Location	Location of unit
Contact	Contact information of administrator of unit
Description #1-3	Additional information regarding the unit

#### NOTE

The name and location will appear on the login and navigation sidebar for convenient identification of the unit.

## System Time

This page allows the administrator to configure the system time manually.

General Settings

---

Information System Time

---

Current Time

**Local Time:** Tuesday June 07, 2016, 05:33:38 AM

**Time Zone:** (GMT+00:00) GMT

---

Manual Clock Settings

**Time Zone:** (GMT+00:00) GMT

**Local Date:** June 7, 2016

**Local Time:** 05 : 33 : 38

---

**Figure 4-4 System Time**

### Current Time

**Local Time** Displays the current local time of the unit.

**Time Zone** Designates the time zone for the unit.

### Manual Clock Settings

**Time Zone** Displays the current time zone configured for the unit.

**Local Date** Manually configure the date of the unit.

**Local Time** Manually configure the time of the unit.

### 4.3.3 IP Settings

This page provides the ability to configure the static IP address and DNS servers of the unit

IP Settings

General

IP Settings

IPv4 Address:	192 . 168 . 1 . 1
IPv4 Subnet Mask:	255 . 255 . 255 . 0
IPv4 Default Gateway:	0 . 0 . 0 . 0

---

Domain Name Server

Primary DNS Server:	0 . 0 . 0 . 0
Secondary DNS Server:	0 . 0 . 0 . 0

Apply

Figure 4-5 IP Settings

### 4.3.4 Unit Alarm

This page displays the current and previous unit alarm conditions, providing quick identification of problems. It provides users the ability to enable alarm features, define alarm trigger criteria, and clear the alarm status. An error is color-coded red to indicate an alarm condition and green to indicate no alarm.

Unit Alarm

General Criteria Details

Unit Alarm Status

Current (ALM LED)	History	Alarm Cut-Off (ACO)
● Off	● Off	Deactivated

---

Unit Alarm Settings

Status	Buzzer	Dry Contact	Action
Enabled ▾	<input type="checkbox"/> Enabled	<input type="checkbox"/> Enabled (Inactive)	▾

Legend

● ON : Unit Alarm is ON	● Flashing : Unit is in Testing Mode
● Off : Unit Alarm is Off	

Apply Refresh

Figure 4-6 Unit Alarm General Settings

### Unit Alarm Status

Current	Displays the current status of the Unit Alarm.
History	Displays if the Unit Alarm was triggered since last cleared.
Alarm Cut-Off (ACO)	Silences the Unit Alarm indicators until the next criteria triggers the alarm.

### Unit Alarm Settings

Status	Enable or disable the Unit Alarm.
Buzzer	Enable or disable the alarm buzzer (audio indicator) when the Unit Alarm has been triggered.
Dry Contact	Enable or disable the alarm relay (remote indicator) when the Unit the Alarm has been triggered.
Action	Active the ACO or clear the alarm history.

## Unit Alarm Criteria

Unit Alarm Criteria are defined by selecting the *Criteria* tab from the Unit Alarm page. This action will bring up the Unit Alarm Criteria page where the user may select the alarm criteria to be monitored by enabling the associated check box. Criteria are divided into categories, which include:

- Telephone/Analog

The screenshot shows the 'Unit Alarm' configuration page with the 'Criteria' tab selected. The page has three tabs: 'General', 'Criteria', and 'Details'. Below the tabs, there is a heading 'Unit Alarm' and a sub-heading 'Criteria'. The main content area contains the following elements:

- A prompt: "Select from the following to indicate which options will trigger the unit alarm..."
- A 'Criteria Category' dropdown menu set to 'Telephone/Analog'.
- A section titled 'Hotlink Triggers' containing a checked checkbox for 'Sync Loss'.
- A section titled 'Session Initiation Protocol Triggers' containing an unchecked checkbox for 'Registration Failure'.
- At the bottom, there are three buttons: 'OK', 'Apply', and 'Refresh'.

Figure 4-7 Unit Alarm Criteria

## Unit Alarm Details

Unit Alarm Details display what alarm criteria are currently triggering the Unit Alarm. A history of the criteria that triggered the Unit Alarm since last cleared can also be viewed from this page.

**Unit Alarm**

General Criteria **Details**

Below lists the criteria that are currently triggering the unit alarm...

**View:**  **Current**  History

**Criteria Category:** Telephone/Analog ▾

Hotlink Triggers

**Sync Loss**

<b>FXS 1 / 1</b>
<input checked="" type="radio"/> Off

SIP Triggers

**Registration Failure**

<b>FXS 1 / 1</b>
<input checked="" type="radio"/> Off

Refresh

**Figure 4-8 Unit Alarm Details Current**

### Unit Alarm

General
Criteria
Details

Below lists the criteria that have been triggered since the alarm was last cleared...

**View:**       Current     **History**

**Criteria Category:** Telephone/Analog ▾

Hotlink Triggers

**Sync Loss**

<b>EXS 1/1</b>
● Off

---

SIP Triggers

**Registration Failure**

<b>EXS 1/1</b>
● Off

**Figure 4-9 Unit Alarm Details History**

### 4.3.5 Advanced

This page provides access to specialized functions. There are icons that link to functions such as: reboot, display product information, and firmware upgrade.

### Advanced

 About   
  Configuration File   
  Users   
  Reboot   
  Restore Defaults   
  Firmware

**Figure 4-10 Advanced Settings**

## About

This page provides you with factory information about the interface card including Product Number, Software Version, Hardware Version and Hardware Serial Number along with TC Communications' contact information.



### About TC1920

<b>Product Number:</b>	12345678901234567890123456789012
<b>Firmware Version:</b>	132.1.4
<b>Hardware Version:</b>	1.1.3-1
<b>Serial Number:</b>	1234567890123456

#### Contact TC Communications

##### Sales

<b>E-Mail:</b>	<a href="mailto:sales@tcomm.com">sales@tcomm.com</a>
<b>Phone Number:</b>	(800) 569-4736 (U.S. Domestic Only)
<b>Office Hours:</b>	7:00 AM to 4:00 PM (U.S. Pacific Standard Time) Monday through Friday

##### Technical Support

<b>E-Mail:</b>	<a href="mailto:technicalsupport@tcomm.com">technicalsupport@tcomm.com</a>
<b>Phone Number:</b>	(949) 852-1973
<b>Office Hours:</b>	8:30 AM to 5:15 PM (U.S. Pacific Standard Time) Monday through Friday

<b>Mailing and Shipping:</b>	TC Communications, Inc. 17881 Cartwright Rd. Irvine, California, USA 92614
------------------------------	--

<b>Website:</b>	<a href="http://www.tcomm.com">http://www.tcomm.com</a>
<b>Phone Number:</b>	(949) 852-1972
<b>Fax Number:</b>	(949) 852-1948

Close

Figure 4-11 About

## Configuration File

This page provides configuration file options for management. Most configuration changes will be saved to the Running Configuration file and will take effect immediately after being applied. The Running Configuration must be saved to the Startup Configuration to ensure that changes remain in effect every time the unit goes through a cold or warm start.



The unit's configurations may be saved and exported to a network location or other storage device. In this way, it is possible to rapidly restore a failed card during troubleshooting by loading the saved configuration file into the unit.

### Configuration File

---

Configuration File

#### Startup Configuration

**Copy From:**  Running Configuration

**Copy To:**  Startup Configuration

---

#### Configuration Load

File Information

**Filename:**  No file selected.

**Load To:**  Startup Configuration  
 Running Configuration

---

#### Configuration Save

File Information

**Save Configuration as:**

**Configuration Type:**  Startup Configuration  
 Running Configuration

**Figure 4-12 Configuration Files**

## Users

This page allows the user to update the Username and Password to access the web management interface.



Login Settings

---

Users

Username:	<input type="text"/>
Current Password:	<input type="password"/>
New Password:	<input type="password"/>
Confirm Password:	<input type="password"/>

---

Apply

**Figure 4-13 Login Settings**

## Reboot

This command initiates a reboot of the unit.



Reboot

---

**Attention**  
Any configurations not yet saved to Startup Configuration will be lost during reboot.  
Click to the right to save configurations: 

Are you sure you want to reboot ?


---

OK Cancel

**Figure 4-14 System Reboot**


## Restore Defaults

You can use this command to reset the unit to factory default settings.



### NOTE


Initiating the Restore Defaults option will reset the card to the default IP Address ( See [1.3.1 Default Software Configuration](#), on page 1-7)



**Figure 4-15 Restore Defaults**

## Firmware

This page provides TC Communications with a method to continuously improve products through feature and reliability firmware upgrades.



**Figure 4-16 Firmware - Upgrade**

## 4.3.6 Telephone/Analog

### 4.3.6.1 Telephone/Analog > Status

The telephone/analog status includes the call status, Hotlink Heartbeat status, and server status.

#### Call Status

This page provides the call statuses for the unit.

Telephone/Analog Status

Port	Hook	Ring	Call Status	Codec
FXS 1/1			 Not in Use	

Refresh

**Figure 4-17 Telephone/Analog Status**

Hook	Displays the on-hook/off-hook status of the port.
Ring	Displays the ringing status of the port.
Call Status	Displays the current call status including the Caller ID of the remote port.
Codec	Displays the codec used during a call in progress.

## Hotlink

This page provides the hotlink information and statuses for the unit.

**Telephone/Analog Status**

Call    Hotlink    Server

**Hotlink:** Hot-Line  
**Heartbeat:** Enabled

	Phone Number	Heartbeat Status
1	201	Sync
2		
3		
4		
5		
6		
7		
8		
9		
10		

Refresh

**Figure 4-18 Telephone/Analog Hotlink Status**

Hotlink	Displays the hotlink mode of the port.
Heartbeat	Displays the heartbeat setting of the port.
Phone Number	Displays the hotlink phone numbers of the port.
Heartbeat Status	Displays the heartbeat status of the hotlink phone numbers.

## Server

This page provides the server statuses of the unit.

Telephone/Analog Status

The screenshot shows a web interface with three tabs: 'Call', 'Hotlink', and 'Server'. The 'Server' tab is active. Below the tabs is a table with three columns: 'Port', 'Registrar', and 'Status'. The 'Port' column contains 'FXS\_1/1', the 'Registrar' column contains 'Using address book', and the 'Status' column is empty. Below the table is a 'Refresh' button.

Port	Registrar	Status
FXS_1/1	Using address book	

Refresh

**Figure 4-19 Telephone/Analog Server Status**

Registrar	Displays the network address of the Registrar server for the port.
Status	Displays the registration status with the server for the port.

### 4.3.6.2 Telephone/Analog > General Settings

The general telephone/analog configurations include SIP, phone number, and server settings.

#### Global Settings

This page provides the global general telephone/analog configurations for the unit.

**General Settings**

Global Port Server

Session Information Protocol (SIP)

<b>SIP Port (1 ~ 65535):</b>	<input type="text" value="5060"/>
<b>Type of Service (ToS):</b>	<input checked="" type="radio"/> Decimal <input type="text" value="104"/> (0 ~ 255) <input type="radio"/> Hexidecimal 0x <input type="text" value="68"/> (00 ~ FF)

---

Real-Time Protocol (RTP)

<b>RTP Base Port (1 ~ 65535):</b>	<input type="text" value="8000"/>
<b>RTCP Base Port (1 ~ 65535):</b>	<input type="text" value="8001"/>
<b>Type of Service (ToS):</b>	<input checked="" type="radio"/> Decimal <input type="text" value="184"/> (0 ~ 255) <input type="radio"/> Hexidecimal 0x <input type="text" value="B8"/> (00 ~ FF)

Apply Refresh

**Figure 4-20 Telephone/Analog General Settings - Global**

## Session Information Protocol (SIP)

SIP Port	<p>Configure the listening port for SIP messages.</p> <p><b>Note:</b> this is the value should be unique for telephone/ analog functionality, i.e. not used by any other process on the platform.</p> <p>When using the Address Book mode, ensure this matches the destination port of the caller set in Address Book.</p> <p>When using SIP Server mode, the server will take care of it automatically.</p> <p>Default is 5060. (This is the standard SIP port. Value should not be changed unless needed for special applications).</p>
Type of Service (ToS)	<p>Configure the DSCP/DiffServ priority for SIP packets.</p>

## Real-Time Protocol (RTP)

Real Time Protocol (RTP) Base Port	<p>Configure the base RTP port. The base RTP port indicates the starting RTP port number.</p> <p>Default is 8000.</p>
RTCP Base Port	<p>Configure the base RTP control port. The base RTCP port indicates the starting RTCP port number.</p> <p>Default is 8001.</p> <p>Ensure there is no overlap between SIP and RTP ports.</p>
Type of Service (ToS)	<p>Configure the DSCP/DiffServ priority for RTP/RTCP packets.</p>

## Port Settings

This page provides the general telephone/analog configurations for a port.

**General Settings**

Global Port Server

<b>SIP Options:</b>	<input type="radio"/> SIP Server <input checked="" type="radio"/> <b>Address Book</b>
<b>Preferred Protocol:</b>	<input checked="" type="radio"/> <b>UDP</b> <input type="radio"/> TCP <input type="radio"/> TLS (Secure)
<b>Phone Number:</b>	<input type="text" value="101"/>
<b>Caller ID Name:</b>	<input type="text"/>
<b>Alarm Relay:</b>	<input type="checkbox"/> On Ring

Apply Refresh

**Figure 4-21 Telephone/Analog General Settings - Port**

SIP Options	<p>Configure one of two options, Address Book or SIP Server.</p> <p>Address Book uses the internal address book to dial to other numbers on the network.</p> <p>SIP Server uses a central SIP server on the network to dial to other numbers.</p>
Preferred Protocol	Configure the format for SIP packets.
Phone Number / SIP User Name	Configure the phone number assigned to each port. It also acts as the SIP User Name when registering to the Registrar Server that requires authentication.

---

Authentication ID	Configure the authentication ID for registering to Registrar Server. (SIP option is "SIP Server" only)
Password	Configure the password for registering to Registrar Server. Along with SIP User Name (Phone Number) and Authentication ID, these settings need to match those on the Registrar Server if authentication is required. (SIP option is "SIP Server" only)
Display Name (Caller ID Name)	Configure the Caller ID Name information to be displayed on the receiving phone station.
Alarm Relay	Configure the phone status to trigger the dry contact alarm relay.

## Server Settings

This page provides the telephone/analog server configurations for a port.

**General Settings**

Global Port **Server**

 **Attention**

The following server settings will only apply when SIP Options is set to 'SIP Server' mode.

**Proxy Server**

**Server Selection:**  Proxy  **Outbound Proxy**

**Proxy Server Address:** IPv4

**UDP Port:**   Default

**Session Expiry (90 ~ 2147483):**  Seconds

**Min. Session Expiry (90 ~ 2147483):**  Seconds

---

**Registrar Server**

Use Proxy Server Address

**Registrar Server Address:** IPv4

**UDP Port:**   Default

**Registrar Expiry (15 ~ 2147483):**  Seconds

Apply Refresh

**Figure 4-22 Telephone/Analog General Settings - Server**

## Proxy Server

Server Selection	<p>Proxy (or Proxy Server) is used to establish, modify, and terminate call sessions. The TC1920 needs to register to the Registrar Server first, which usually has the same address as the Proxy Server.</p> <p>Outbound Proxy is a proxy server that receives requests from clients, even though it may not be the server resolved by the Request-URI. It is similar to Proxy except it receives a request from TC1920 even if the Request-URI of the message indicates another server. In short, all messages from TC1920 must pass through Outbound Proxy if it is set.</p> <p>In some cases, the Outbound Proxy is placed alongside the firewall and is the only way to allow SIP traffic to pass from the internal private network to the Internet therefore acting as a gatekeeper.</p>
Proxy Server Address	<p>Configure the address of the Proxy Server or Outbound Proxy Server as an IP address or hostname.</p>
UDP Port	<p>Configure the UDP port number of the proxy server listening port. The value setting here should match the SIP Port.</p> <p>Default is 5060.</p>
Session Expiry	<p>Configure the refresh duration of the session. The TC1920 will resend "INVITE" every other time which is approximately half of "Session Expiry" value and negotiated Session-Expires header will be seen in 200 OK reply of first INVITE message.</p> <p>Default is 1800.</p>
Min. Session Expiry	<p>Configure the minimum expiry interval that can be used for a session.</p> <p>Default is 100.</p>

## Registrar Server

Use Proxy Server Address	<p>Check to use the Proxy Server address for the Registrar Server address.</p> <p>If the Registrar server address and Proxy server address are different then the REGISTER message will not pass through Proxy, but if Outbound Proxy is configured then the REGISTER message must pass through Outbound Proxy.</p>
Registrar Server Address	Configure the address of the Registrar server address as an IP address or hostname.
UDP Port	Configure the UDP port number of the Registrar Server listening port. Default is 5060.
Registrar Expiry	Configure the expiry time in seconds for the registration with SIP Server. The TC1920 will resend REGISTER message to the Registrar Server based on the time configured.

### 4.3.6.3 Telephone/Analog > Address Book

This page provides the telephone/analog internal address book configurations for the unit.

---

<b>NOTE</b>	The SIP Options must be set to “Address Book” in the Telephone/Analog general port settings page (see <a href="#">Port Settings</a> , on page 4-22).
-------------	--

---

#### Entries

The address book is used instead of the SIP Server phone number assignment and allows each of the individual TC1920 Telephone/Analog units to communicate with each other over the Ethernet network. For each unit that is installed in the network, annotate the IP address of the unit and compare this IP Address with the phone numbers definitions assigned to the FXS ports.

**NOTE** To enable the address book for your network, it is necessary to define the phone number ranges of the installed TC1920s and corresponding mapped IP Addresses. To simplify this operation, the option of saving your address book to file allows the loading of multiple units with the required information.

**Address Book**

Entries Load/Save

Page: Page 1: 1 ~ 4

Search for phone number:  Find Clear

Entry	Phone Number	Destination	
		IP Address	UDP Port
1	101	192.168.1.1	5060
2	102	192.168.1.1	5060
3	201	192.168.1.2	5060
4	202	192.168.1.2	5060

Refresh

**Figure 4-23 Telephone/Analog - Address Book Entries**

Page	Select the page number of the address book to display.
Entry	Address book entry number.
Phone Number	Displays the phone number of the address book entry.
Address	Displays the destination address of the address book entry.
UDP Port	Displays the UDP port number of the address book entry.

**NOTE** Apply button must be clicked on the main address book page for changes to take effect.

## Entry Add/Edit

Address Book

---

Entries Load/Save

**Port:** FXS 1/1

**Address Book:** FXS 1/1

---

**Entry**

**Phone Number List:** 101

---

**Destination**

**IP Address:** 192 . 168 . 1 . 1

**UDP Port:** 5060  Use SIP Port

---

OK Apply Cancel

**Figure 4-24 Telephone/Analog Address Book Entry Add/Edit**

**Address Book** Displays the port number of the address book entry.

### Entry

**Phone Number List** Configure the list phone number(s) dialed locally

### Destination

**IP Address** Configure the address of the destination for the phone number(s) specified.

**UDP Port** Configure the UDP port number of the packets sent out.

## Load/Save

### Address Book

Entries Load/Save

Address Book Load

File Information

**Filename:**  No file selected.

**Load to Flash only:**  Do not apply to database

Address Book Save

File Information

**Save Address Book as:**

**Figure 4-25 Telephone/Analog Address Book Load/Save**

Address Book Load	Download an address book file from the local PC to the port.
Address Book Save	Upload an address book file to the local PC from the port.

#### 4.3.6.4 Telephone/Analog > Dial Features

This page provides configurations for dialing features on the unit.

##### Hotlink

Hot links are lines that are set to automatically connect to the caller when the calling line goes “Off-Hook” based on a pre-defined hierarchy. Using the Hot Links function, you may define up to ten numbers that will have priority connect hierarchy when making a call.

When the user picks up a phone, it will automatically dial the pre-defined phone numbers set for the corresponding port shown on this page. A maximum of ten numbers can be entered, they will all ring simultaneously (if not busy), and whoever answers first will establish connection.

Up to ten phone numbers can be called simultaneously, and the first to answer establishes connection and all other lines will be released.

##### NOTE

All numbers listed should be FXS only or FXO only to prevent connection issues.

**Dial Features**

Hot Link      Group Dial

**Hot Link:**       Disabled       Hot-Line       Warm-Line

**Warm-Line Delay:**       Seconds

Phone Numbers	Heartbeat	Heartbeat Status
1. <input type="text" value="201"/>	<input checked="" type="checkbox"/> Enabled	Sync
2. <input type="text"/>	<input type="checkbox"/> Enabled	
3. <input type="text"/>	<input type="checkbox"/> Enabled	
4. <input type="text"/>	<input type="checkbox"/> Enabled	
5. <input type="text"/>	<input type="checkbox"/> Enabled	
6. <input type="text"/>	<input type="checkbox"/> Enabled	
7. <input type="text"/>	<input type="checkbox"/> Enabled	
8. <input type="text"/>	<input type="checkbox"/> Enabled	
9. <input type="text"/>	<input type="checkbox"/> Enabled	
10. <input type="text"/>	<input type="checkbox"/> Enabled	

**Figure 4-26 Telephone/Analog Hot Link**

Hot Link	<p>Enable Hot-Line or Warm-Line to automatically dial phone numbers pre-defined in the table when a port goes off-hook.</p> <p>Hot-Line will auto-dial phone numbers immediately after off-hook.</p> <p>Warm-Line allows for a delay, in seconds, after off-hook to dial a phone number before auto-dialing phone numbers.</p>
Phone Numbers	<p>The phone numbers entered in the table are automatically dialed after the port goes off-hook.</p>

### **Hotlink Heartbeat**

This feature checks if the hotlink phone numbers are alive and responsive. Phone numbers that do not respond and timeout are considered lost. The heartbeat status can be used to trigger an alarm.

Heartbeat	<p>Enable the heartbeat monitoring for each hotlink phone number.</p>
Heartbeat Status	<p>Displays the heartbeat status of each hotlink phone number.</p>

## Group Dial

Group Dial assigns a group phone number to a list of phone numbers.

When the user dials the group phone number, it will automatically dial the pre-defined phone numbers set for the corresponding port shown on this page. A maximum of ten group numbers can be created, and up to twenty numbers can be entered for each group, they will all ring simultaneously (if not busy), and whoever answers first will establish connection and all other lines will be released.

### NOTE

All member phone numbers listed should be FXS only or FXO only to prevent connection issues.

### Dial Features

Hot Link

Group Dial

**Group Dial:**

Enabled
  Disabled

**Group:**

**Phone Number :**

Member Phone Numbers	
1.	<input type="text"/>
2.	<input type="text"/>
3.	<input type="text"/>
4.	<input type="text"/>
5.	<input type="text"/>
6.	<input type="text"/>
7.	<input type="text"/>
8.	<input type="text"/>
9.	<input type="text"/>
10.	<input type="text"/>
11.	<input type="text"/>
12.	<input type="text"/>
13.	<input type="text"/>
14.	<input type="text"/>
15.	<input type="text"/>
16.	<input type="text"/>
17.	<input type="text"/>
18.	<input type="text"/>
19.	<input type="text"/>
20.	<input type="text"/>

**Figure 4-27 Telephone/Analog Group Dial**

Group Dial	Enable or disable group dialing for the port.
Group	Select the group phone number to configure.
Phone Number	Appears when a new group number is being configured to set the phone number of the group.
Member Phone Numbers	The phone numbers entered in the table are rung when the group phone number is dialed.

#### 4.3.6.5 Telephone/Analog > Codecs

In telephone/analog the analog voice signal is digitalized and compressed using a codec algorithm.

##### Global Settings

This page provides configurations for the codecs supported on the unit.

Codecs

Global Port

Codec Settings

Codec	Bit Rate	VAD	PTime	Mapped Payload
G.711 $\mu$ -Law	64 Kbps	Disabled ▾	20 ▾ ms	0
G.711 A-Law	64 Kbps	Disabled ▾	20 ▾ ms	8
G.726	16 Kbps	Disabled ▾	20 ▾ ms	98
G.726	32 Kbps	Disabled ▾	20 ▾ ms	2
G.729A	8 Kbps	Disabled ▾	20 ▾ ms	18

**Legend**

VAD: Voice Activity Detection	PTime: Packetization Time
-------------------------------	---------------------------

Apply Refresh

Figure 4-28 Telephone/Analog Codec Settings

## Codec Settings

Bit Rate	Displays the bit rate of the codec.
VAD	Voice Activity Detection separates conversational speech and silence. It is used to reduce bandwidth usage during idle periods of a conversation. Comfort Noise will be generated to fill the silence in a transmission.
PTime	Packetization Time is the time length of each voice packet.
Mapped Payload	Configure the dynamic variable payload of the codec. G.711 $\mu$ -law, G.711 A-Law, G.726-32, G.726-16, and G.729A are codecs that are assigned with static payload, so the configuration is grayed out.

## Port Settings

Codecs may be assigned independently to each port.

Codecs

---

Global
Port

Codec Selection

Codecs			
1. G.711 $\mu$ -Law	2. G.711 A-Law	3. G.726-16 Kbps	4. G.726-32 Kbps
5. G.729A			

---

Codec Settings

**G.726 Encoding Format:**  ITU-T  IETF

---

Fax Settings

**T.38 Support:**  T.38  Pass-Through

**T.38 LSR Level:** 3

**T.38 HSR Level:** 1

**Figure 4-29 Telephone/Analog Port Codec Settings**

### Codec Selection

**Codecs** Select the codecs in order according to preference. The matching codec will be negotiated between caller and callee.

### Codec Settings

**G.726 Encoding Format** Configure either ITU-T or IETF encoding format for G.726 codec. These are two different format of encoding/decoding G.726 packets defined by IETF standard and ITU-T standard.

### Fax Settings

**T.38 Support** If T.38 is disabled, fax packets will be sent in pass-through mode with the selected codec. If T.38 is enabled, fax packets will be sent following the T.38 protocol.

T.38 only works with fax machines that support G3 protocol. If the fax machine supports Super G3 protocol, disable T.38 to fax in Pass-Through mode. Fax Rate is fixed at 14.4 kbps.

**T.38 LSR Level** Configure the recovery level for V21 handshake data.

**T.38 HSR Level** Configure the recovery level for high speed image data.

LSR and HSR parameters are useful to recover from fax transfer error due to loss of packets in a network. Higher values allow better chance of recovery from error.

### 4.3.6.6 Telephone/Analog > Call Features

This page provides calling features on the unit.

#### Global Settings

This page provides global calling feature configurations.

Telephone/Analog Call Features

---

Global Port

---

Dialing

Maximum number of digits to dial (1 ~ 60):

---

Timers

Ringing/Ringback Timer (10 ~ 255):  seconds until disconnect

---

**Figure 4-30 Telephone/Analog Call Features Settings**

#### Dialing

Maximum number of digits to dial The maximum number of digits that are allowed to be entered before dialing. If a number with fewer digits is dialed, then # can be entered to start dial immediately.

#### Timers

Ringing/Ringback Timer The number of seconds a call can ring before getting disconnected.

## Port Settings

This page provides calling feature configurations for the port.

**Call Features**

---

Global **Port**

---

**General Settings**

**Voice Volume:**  **Echo Canceler:**

**DTMF Transport:**

---

**Caller ID**

**Display incoming Caller ID**  Block outgoing Caller ID  Anonymous Call Barring

---

**Call Forwarding**

**Disabled**

Forward all calls to:

Forward call...

When busy to:

When unanswered to:

Forward after  seconds

---

**Figure 4-31 Port Call Features Settings**

### General Settings

Voice Volume	Configure the voice volume during a call. Higher value increases the volume.
Echo Canceler	Enable or disable echo cancellation.
DTMF Transport	Select how dialed digit information is transmitted during a call.

### Caller ID

Display incoming Caller ID      Enable to display Caller ID of incoming call.

Block outgoing Caller ID      Enable to make calls anonymously.

Anonymous Call Barring      Enable to block anonymous incoming calls.

### Call Forwarding

Forward all calls      Forward all incoming calls to the phone number configured.

Forward calls when busy      During a call, forward all incoming calls to the phone number configured.

Forward calls when unanswered      Forward all unanswered calls to the phone number configured.

### 4.3.6.7 Telephone/Analog > Security

Telephone/Analog can be secured with authentication and encryption.

#### SRTP

Secure Real-Time Protocol adds authentication and encryption to voice communication.

**Security Settings**

SRTP (Secure Real-Time Protocol) is used to secure the voice communication.

SRTP	TLS	TLS Certificate
SRTP (Secure Real-Time Protocol) is used to secure the voice communication.		
<b>SRTP:</b>	<input type="radio"/> Enabled <input checked="" type="radio"/> <b>Disabled</b>	
<b>CryptoSuite:</b>	128-bit AES-CM, 80-bit SHA-1 ▼	
<b>SRTP Encryption:</b>	<input checked="" type="radio"/> <b>Enabled</b> <input type="radio"/> Disabled	
<b>SRTCP Encryption:</b>	<input checked="" type="radio"/> <b>Enabled</b> <input type="radio"/> Disabled	
<b>SRTP Authentication:</b>	<input checked="" type="radio"/> <b>Enabled</b> <input type="radio"/> Disabled	
<b>MKI Length (0 ~ 127):</b>	<input type="text" value="0"/>	
<b>Key Lifetime:</b>	10 ▼	
<b>Derivation Rate:</b>	10 ▼	

**Figure 4-32 Telephone/Analog SRTP Settings**

SRTP	Enable or disable voice security.
CryptoSuite	Select the security method.
SRTP Encryption	Enable or disable encryption of SRTP.
SRTCP Encryption	Enable or disable encryption of SRTCP.
SRTP Authentication	Enable or disable authentication of SRTP.
MKI Length	Configure the master key identifier length.
Key Lifetime	Configure the maximum key length.
Derivation Rate	Configure the derivation rate of the key.

## TLS

Transport Layer Security adds authentication and encryption to SIP communication.

**Security Settings**

SRTP    **TLS**    TLS Certificate

TLS (Transport Layer Security) is used to secure the SIP communication.

**Global Settings**

**Security Level:**

**Port Settings**

Port	Preferred Protocol		
FXS 1/1	<input type="radio"/> TLS (Secure)	<input checked="" type="radio"/> UDP	<input type="radio"/> TCP
FXS 1/2	<input type="radio"/> TLS (Secure)	<input checked="" type="radio"/> UDP	<input type="radio"/> TCP

**Figure 4-33 Telephone/Analog TLS Settings**

### Global Settings

**Security Level**    Level 1 security encrypts the SIP header.  
 Level 2 security encrypts the entire SIP message.

### Port Settings

**Preferred Protocol**    Shortcut to the configuration described in Section (General Port Settings).

## TLS Certificate

This page provides the upload and download options for the TLS certificates.

**Security Settings**

SRTPTLS**TLS Certificate**

**Status**

<b>Certificate:</b>	No certificate loaded
<b>CA Certificate:</b>	No certificate loaded

**Load** Load Certificate

Certificate Information

<b>Certificate:</b>	<input type="radio"/> Certificate <input checked="" type="radio"/> CA Certificate
<b>Filename:</b>	<input type="button" value="Browse..."/> No file selected.

**Save** Save Certificate

Certificate Information

<b>Certificate:</b>	<input checked="" type="radio"/> Certificate <input type="radio"/> CA Certificate
<b>Save as:</b>	<input type="text" value="Certificate.pem"/>

**Figure 4-34 Telephone/Analog TLS Certificate Status/Load/Save**

### Status

Certificate	Displays the status of the certificate loaded to the unit.
CA Certificate	Displays the status of the certificate authority used for validating the certificate.

### Load

Certificate	Select whether to download the certificate or certificate authority from the local PC to the unit.
Filename	Browse for the certificate (.pem) on the local PC.

## Save


Certificate	Select whether to upload the certificate or certificate authority to the local PC from the unit.
Save as	Enter in the filename of the certificate to be downloaded as to the local PC.

### 4.3.6.8 Telephone/Analog > Tones

The tones used on the device can be configured.

#### General

This page provides general settings for the tones.



The screenshot shows a web interface titled "Tone Configurations". It has three tabs: "General", "Generation (FXS)", and "Detection (FXO)". The "General" tab is selected. Under the "Volume" section, there is a label "Tone Volume:" followed by a dropdown menu currently showing the value "4". At the bottom of the page, there are two buttons: "Apply" and "Refresh".

**Figure 4-35 Telephone/Analog Tones Settings**

#### Volume

Tone Volume	Configure the volume the tones. Higher value increases the volume.
-------------	--

## Generation

This page provides configurations for the tones generated. All tones can be set to preset country tones or customized.

### Tone Configurations

General
Generation (FXS)
Detection (FXO)

Dial Tone United States ▾  Share all presets

Frequency 1	Frequency 2	AM Frequency	Cadence 1		Cadence 2	
			On Time	Off Time	On Time	Off Time
350 Hz	440 Hz	0 Hz	0 ms	0 ms	0 ms	0 ms

---

Busy Tone United States ▾

Frequency 1	Frequency 2	AM Frequency	Cadence 1		Cadence 2	
			On Time	Off Time	On Time	Off Time
480 Hz	620 Hz	0 Hz	500 ms	500 ms	0 ms	0 ms

---

Ringback Tone United States ▾

Frequency 1	Frequency 2	AM Frequency	Cadence 1		Cadence 2	
			On Time	Off Time	On Time	Off Time
440 Hz	480 Hz	0 Hz	2000 ms	4000 ms	0 ms	0 ms

**Legend**

Frequency: 0 ~ 700 Hz

Cadence: 0 ~ 8000 ms (For a continuous tone, set all On and Off Times to '0')

Apply Refresh

**Figure 4-36 Telephone/Analog Tones Generation Settings**

Dial Tone	The tone heard before a phone number is dialed.
Busy Tone	The tone heard when a dialed line is busy.
Ringback Tone	The tone heard after a phone number is dialed and the remote phone is ringing.

## Detection

This page provides configurations for the tones detected. All tones can be set to preset country tones or customized.

Busy, Reorder, and two custom tones can be configured detect when a call should be disconnected.

### VoIP Tone Configurations

General
Generation (FXS)
Detection (FXO)

**Disconnect on Tone:**  Enabled  Disabled

**Standard Tones**

Tone	Preset	Frequency 1	Frequency 2	Cadence 1	
				On Time	Off Time
Busy Tone	United States ▼	480 Hz	620 Hz	500 ms	500 ms
Reorder Tone	United States ▼	480 Hz	620 Hz	500 ms	500 ms

**Custom Tones**

Tone	Frequency 1	Frequency 2	Cadence 1	
			On Time	Off Time
Custom 1	0 Hz	0 Hz	0 ms	0 ms
Custom 2	0 Hz	0 Hz	0 ms	0 ms

**Legend**

Frequency:	0 ~ 700 Hz
Cadence:	0 ~ 8000 ms (For a continuous tone, set all On and Off Times to '0')

**Figure 4-37 Telephone/Analog Tones Detection Settings**

Disconnect on  
Tone

Enable and disable disconnect on tone detection.

## 5.1 Introduction

Troubleshooting involves a systematic approach to isolate an observed problem and then determine the action needed to fix the problem. This process usually reveals several possible causes and solutions. Select the most probable cause and test the solutions.

This chapter has several sections to aid the technician in troubleshooting problems or errors.

- The first step is to use the LED front and back panel indicators for power, serial connections and operation alarms.
- The second step is using TC Communication's web management application which shows alarms conditions and error message pop ups.
- The third step is to inspect is mechanical problems that and may involve cables or equipment the TC1920 is connected to such as the fax machines, phones, Ethernet hubs, etc.

## 5.2 Strategy for Troubleshooting

A good troubleshooting strategy involves a systematic approach that starts with:

- isolating the problem
- determining the likely cause
- implementing a solution to the problem
- verify the unit configurations are correct

This manual does not cover every possible problem. The intent is to guide you to possible solutions when experiencing a particular problem.

---

**NOTE**

If the problem is too complex for the instructions contained in this chapter, call TC communications customer service for assistance.

---

Troubleshooting strategy:

- a. Determine the most likely category of the failure.
- b. Read the manual for suggestions on possible causes and solutions.
- c. Test the most likely causes and solutions to eliminate the obvious (example: swap out bad cables, use a DVM to test input voltages).

- d. If you have more than one TC1920, does the problem occur on more than one unit?
- e. If one unit works properly and another does not, test the suspected component to determine if the problem repeats itself.

The following approach helps narrow the scope of the problem:

- Was the change sudden, or a gradual decline past the threshold of acceptable performance?
- Determine whether the problem was caused by the unit or for example, by a change in the any settings. outside the system that may cause a problem (i.e. fax machines, telephone handsets, etc.)
- Was a unit replaced and the original settings not duplicated exactly on the replacement unit.
- Is the problem limited to one unit, or has it shown up on many?
- Did the problem develop after a string of quick-fix failures?
- Perform the following:
  - a. Document any event that preceded the failure or error.
  - b. Check the list of [Common Problems](#), on page 5-2 and determine if the problem is consistent with the items listed.

---

**NOTICE**

Do not, for any reason, open the TC1920 unit. If you suspect of any problems with the unit, contact the Technical Support Department at TC Communications, Inc. for assistance. If the unit is opened without prior authorization from TC, it will result in the loss of warranty.

---

### 5.2.1 Common Problems

Most problems usually can be grouped in the following categories:

- [Mechanical](#), on page 5-3
  - [Environment](#), on page 5-3
  - [Cabling](#), on page 5-3
- [Electrical](#), on page 5-5
  - [Power Supplies](#), on page 5-11
- [Software](#), on page 5-12

## 5.3 Mechanical

This section will inform you about the types of problems associated with environmental or cabling issues that lead to replacing and installing the component or housing.

### 5.3.1 Environment

The location and the environmental condition can contribute to problems encountered with system operation.

**Table 5-1: Environmental Errors**

Symptoms	Possible Cause	Actions
Intermittent signal or power loss with an alarm.	Indications of damage to the cable or connectors.	a. Replace the cables.
There is a front panel alarm and verification on Unit Alarm Status shown as a temperature alarm.	The operating area is not free from extremes of temperature or humidity beyond the specifications.	Provide protection from extreme conditions as shown in <a href="#">Specifications</a> , on page 1-6 or replace with upgraded model.

---

**NOTICE** If copper cable(s) connected to TC1920 unit(s) are located outside buildings or enclosures (even at minimal distances), TC1920 units may be damaged by lightning and/or electrical power surges.

Adding protective devices (surge suppressors/lighting protectors) to each copper cable that is exposed to potential lightning strikes or power surges is highly recommended. Please be aware that adding such protective devices can't guarantee 100 percent protection for connected electronic equipment. You should contact a professional lightning/surge protection consultant for specific questions regarding your application.


---

### 5.3.2 Cabling

There are two types of interface connectors used on the TC1920 front panel.

- RJ-11 (Registered Jack) is used for the FXS lines. The standard connector is used on 2-pair (4-wire) telephone lines.
- The RJ-45 socket fits an 8-position modular connector that looks like a large phone plug. The connector is the weak point in any ethernet cable. See [Ethernet Port RJ-45 Pin Assignment](#), on page 2-7.

**Table 5-1: Cable Configurations**

<p><b>RJ-11 FXS connectors are used for modular telephone and LAN</b></p>	
<p><b>RJ-45 Ethernet connection</b></p>	

**Table 5-2: Cables**

Symptoms	Possible Cause	Actions
<ul style="list-style-type: none"> <li>• Intermittent signal with an alarm.</li> <li>• Front panel LED is Off.</li> </ul>	The port is not working.	Try the following steps;
	The cable has been damaged internally.	<ul style="list-style-type: none"> <li>• Inspect for physical damage.</li> </ul>
	The connector is damaged or the plug is fouled with contamination.	<ul style="list-style-type: none"> <li>• Use A DVM to test the cable signal output at the connector.</li> <li>• Replace the cable with a known good cable.</li> </ul>
Intermittent signal or power loss with an alarm.	Indications of damage to cable or connectors.	b. Replace the cables.
No FXS dial tone on line.	Defective connector.	Replace the cable.
	Defective telephone handset.	Replace the unit and ensure the is a dial tone.

## 5.4 Electrical

Often the quickest way to troubleshoot is to replace components and check the results. Use known good components for the replacement, and keep track of which original components belong to a specific rack and their settings. Individual settings may prevent or interfere with operations in another TC1920 unit.

### 5.4.1 Using Front Panel Indicator LEDs For Diagnostics

Unit LEDs include:

- *Power Source A and B (PWR) on page 5-6*
- *Power On (Vcc) on page 5-6*
- *Alarm on page 5-7*
- *Link on page 5-7*
- *BP1 and BP2 on page 5-7*
- *Compression Ratio (CP-R) on page 5-8*
- *Volume TX and RX on page 5-8*
- *FXS on page 5-8*
- *Master/Slave on page 5-9*
- *Telephone/Analog Panel Ports on page 5-9*

**NOTE**


There is the possibility that the LED itself has failed and is not showing the current condition. Call TC Communications customer service for assistance if you suspect this to be the case.

#### 5.4.1.1 Power-up LED Verification Sequence

The LEDs, except PWR A, PWR B, and Vcc, will flash for 3 seconds during power up. If an LED does not flash, it has most likely failed.

### 5.4.1.2 Power Source A and B (PWR)

Power modules A and B are continuously monitored. The system uses both power supplies simultaneously, and in the event of the loss of one power supply, will continue to operate on the other power supply.




#### PWR LED Behaviors

LED	Condition
Solid	Power is being supplied from module.
Off	Power is not being supplied from module.
	Power module has failed.
	Fuse on card has burned.

### 5.4.1.3 Power On (Vcc)

The Vcc LED indicates the unit is receiving enough voltage for proper operation.




#### Vcc LED Behavior

LED	Condition
Solid	5 VDC is good.
Off	No 5 VDC is supplied.

### 5.4.1.4 Ready (RDY)

The RDY LED indicates when the unit has finished initialization and is operating properly.




#### RDY LED Behavior

LED	Condition
Solid	Unit is ready for use.
Fast Flash	Flash operation in progress. Do not power off unit until operations have completed.
Slow Flash	Unit is booting.

### 5.4.1.5 Alarm

The LED will illuminate solid red, and the dry contact relay (if present) will close when an alarm condition is detected. The user can configure which types of alarms will trigger the unit alarm.

Normally in the OPEN position, any alarm condition will trigger the switch to the CLOSED position. The switch position is controlled by a relay inside the TC1920.




#### ALM LED Behaviors

LED	Condition
Solid	Unit Alarm is triggered.
Off	Unit Alarm is not triggered.
Flash On	Unit Alarm has been triggered since last cleared.
Steady Flash	Unit is in testing/diagnostic mode.

### 5.4.1.6 Link

The LED indicates the link status summary between the local and remote units.




#### LINK LED Behaviors

LED	Condition
Solid	Link established with remote unit.
Flash	Unable to establish link with remote unit.
Off	Hotlink heartbeat is disabled.

### 5.4.1.7 BP1 and BP2

These LEDs indicates the link status of the Ethernet ports on the back of the unit.



#### BP1 and BP2 LED Behaviors

LED	Condition
Solid	Ethernet link is established.
Flash	Ethernet Tx/Rx activity detected.
Off	Ethernet link not established.

### 5.4.1.8 Compression Ratio (CP-R)

These LEDs indicate the compression rate enabled on the unit, as well as the rate used during a call in progress. Auto-negotiation of the compression rate is indicated by all LEDs solid.




#### CP-R LED Behaviors

64K/32K/16K/8K LED	Condition
<b>Idle</b>	
Solid	Compression rate is enabled and available for use during a call.
Off	Compression rate is disabled
<b>Call in Progress</b>	
Flash	The compression rate used during a call
Off	Compression rate is not in use.

### 5.4.1.9 Volume TX and RX


The **TX** LED displays the detected volume of the signal coming out of port from the remote side.

The **RX** LED displays the detected volume of signal going into port from at the local side.



### 5.4.1.10 FXS

The LED indicates the unit has an FXS port.




#### FXS LED Behaviors

FXS LED	Condition
Solid	Unit has FXS port and is ready to use.
Flash	Unit is re-configuring. Calls cannot be made during this time.
Off	Unit does not have FXS port.

### 5.4.1.11 Master/Slave

These LEDs indicate whether the unit is currently set in Master or Slave pairing mode.



#### Master/Slave LED Behaviors

MSTR LED	SLVE LED	Condition
Solid	Off	Unit is Master.
Off	Solid	Unit is Slave.
Off	Off	Unit is not in Master/Slave mode.

### 5.4.1.12 Telephone/Analog Panel Ports

This unit has one phone/line port that is FXS:



Figure 5-1 Phone/Line Port



Figure 5-2 Phone/Line LEDs


#### Phone/Line LED Behaviors

HOOK LED	RING LED	Condition
Solid	N/A	Port is off-hook.
Off	Fast Flash	Port is on-hook and ringing.
Solid	Flash On	Call is connecting.
Solid	Solid	Call is in progress.
Off	Off	Port is on-hook and not ringing.

HT-L LED	Condition
Solid	Hotlink is enabled and configured properly.
Flash Green	Hotlink is enabled, but not configured properly.
Off	Hotlink is disabled.

#### 5.4.1.13 Ethernet Ports

The unit has two FastEthernet ports on the back of the unit.



#### Ethernet Ports LED Behaviors

LINK LED	DUP LED	Condition
Solid	Solid	Link is established at Full Duplex.
	Off	Link is established at Half Duplex.
Flash	N/A	Link activity is detected.
Off	Off	Port is not connected.
		Power is disabled.

## 5.4.2 Power Supplies

There are several power supply options available. See [Specifications](#), on page 1-6.

### To inspect the stand alone power supply

- ❖ When the power is applied, determine if the front panel LED is green or off.



If	Then
The power supply LED A and B are green.	Proceed.
The LED is off.	This indicates a problem with the power source, the power supply or the connector. Please see the troubleshooting section, <a href="#">Power Supplies</a> , on page 5-11.



**Figure 5-3 TC1920 Back Panel Connectors and Indicators**

### To inspect the power supply

- ❖ Determine if the front or rear panel LED is green or Off.

If	Then
The LED is green.	Proceed.  
The LED is off.	This indicates; <ul style="list-style-type: none"> <li>• a problem with the power source</li> <li>• a problem with the power supply or the connector</li> <li>• the power supply port is unused.</li> </ul> Please see <a href="#">Power Supplies</a> , on page 5-11.  

## 5.5 Software

The [Management through the Web](#) chapter defines and describes on each screen in GUI the parameters, options, buttons and commands. This section has information on diagnosing and repairing the unit.

<b>NOTE</b>	TC Communications provides software upgrades to ensure improve performance, adding new features, and correct problems (bugs). Please refer to the documents that are included in your documentation package for complete details for your software revision. The upgrade procedure is in <a href="#">Firmware Upgrade</a> , on page 5-11.
-------------	---

### 5.5.1 Default Software Configuration

The quick-start chapter describes how to perform the TC1920 unit initial setup in a typical network application. This includes software configuration. The default software configuration is detailed in the tables shown in [Default Software Configuration](#), on page 1-7.

## 5.5.2 Resolving Software Problems

Possible causes and suggested corrective actions are listed below for some problems. You need to have Administrative access to correct some situations.

### 5.5.2.1 Address Book

The Telephone/Analog Address Book page provides the method of defining your phone network; phone numbers related to IP address for one or multiple SIP-compatible devices on the network.

**Table 5-3: Address Book**

Symptoms	Possible Cause	Actions
Phone number and IP Address entered is not showing up.	The apply button may not have been clicked.	If the correct address book was saved on the PC, use <i>To recover from a missing phone book address</i> , on page 5-13.  Re-enter the phone number and IP Address again and select the Apply icon.
Dialed the number and there was a busy tone.	The phone address may not be in the book.	

#### To recover from a missing phone book address

1. From the Navigation Menu select the Telephone/Analog icon.  
*The Advanced page appears. See [Advanced](#), on page 5-6.*
2. From the Navigation Menu select the Address Book icon.  
*The Telephone/Analog Address Book page appears.*
3. Select the Load command button.
4. Select the *Browse* command button.  
*A Choose File popup appears.*
5. Locate the address file from the popup, highlight it, and select Open.
6. Select the Apply command button.

### 5.5.2.2 Ethernet Connection

The TC1920 extends services to remote locations from the control center over existing infrastructure by interfacing with the Ethernet network via an RJ-45 Ethernet connection. For pin assignments see the table [Ethernet Port RJ-45 Pin Assignment](#), on page 2-7.

**Table 5-4: Ethernet Connection**

Symptoms	Possible Cause	Actions
Cannot connect (ping) TC1920 units.	<ul style="list-style-type: none"> <li>Incompatible with WAN and LAN environments.</li> <li>Pinged the wrong address.</li> </ul>	<ul style="list-style-type: none"> <li>Ensure the PC is under the same subnet as the other TC1920 units.</li> <li>Restore the default settings.</li> </ul>
Link is not detected.	Cable or connector damaged.	See <a href="#">Cabling</a> , on page 5-3.
	The TC1920 is not connected to a working Ethernet port.	Ensure the Ethernet port that the TC1920 is connected to is operating correctly.

### 5.5.2.3 Password

Login with default username is "*admin*" and the password is "*admin*." The computer administrator account has full access to the TC1920 graphic user interface. Leaving the system with the default administrator settings allows open access to your computer.

**Table 5-5: Password**

Symptoms	Possible Cause	Actions
The password is not accepted.	The password <b>is</b> case-sensitive.	Re-enter the password. If this fails, the administrator must reset the password.
The name is not accepted.	The user name <b>is</b> case-sensitive.	Re-enter the name. If this fails, the administrator must reset the name.
Forgot the password.	N/A	Reset the card to the default settings and then reprogram the configuration settings.

## A.1 Return Policy

To return a product, you must first obtain a Return Material Authorization number from the Customer Service Department. If the product's warranty has expired, you will need to provide a purchase order to authorize the repair. When returning a product for a suspected failure, please provide a description of the problem and any results of diagnostic tests that have been conducted.

### A.1.1 Warranty

Damages by lightning or power surges are not covered under this warranty.

All products manufactured by TC Communications, Inc. come with a five year (beginning 1-1-02) warranty. TC Communications, Inc. warrants to the Buyer that all goods sold will perform in accordance with the applicable data sheets, drawings or written specifications. It also warrants that, at the time of sale, the goods will be free from defects in material or workmanship. This warranty shall apply for a period of five years from the date of shipment, unless goods have been subject to misuse, neglect, altered or destroyed serial number labels, accidents (damages caused in whole or in part to accident, lightning, power surge, floods, fires, earthquakes, natural disasters, or Acts of God.), improper installation or maintenance, or alteration or repair by anyone other than Seller or its authorized representative.

Buyer should notify TC Communications, Inc. promptly in writing of any claim based upon warranty, and TC Communications, Inc., at its option, may first inspect such goods at the premises of the Buyer, or may give written authorization to Buyer to return the goods to TC Communications, Inc., transportation charges prepaid, for examination by TC Communications, Inc. Buyer shall bear the risk of loss until all goods authorized to be returned are delivered to TC Communications, Inc. TC Communications, Inc. shall not be liable for any inspection, packing or labor costs in connection with the return of goods.

In the event that TC Communications, Inc. breaches its obligation of warranty, the sole and exclusive remedy of the Buyer is limited to replacement, repair or credit of the purchase price, at TC Communications, Inc.'s option.

To return a product, you must first obtain a Return Material Authorization (RMA) number and RMA form from the Customer Service Department. If the product's warranty has expired, you will need to provide a purchase order to authorize the repair. When returning a product for a suspected failure, please fill out RMA form provided with a description of the problem(s) and any results of diagnostic tests that have been conducted. The shipping expense to TC Communications should be prepaid. The product should be properly packaged and insured. After the product is repaired, TC Communications will ship the product back to the shipper at TC's cost to U.S. domestic destinations. (Foreign customers are responsible for all shipping costs, duties and taxes [both ways]. We will reject any packages with airway bill indicating TC communications is responsible for Duties and Taxes. To avoid Customs Duties and Taxes, please include proper documents indicating the product(s) are returned for repair/retest).

### **A.1.2 Limitation of Liability**

1. In no event shall the total liability of TC COMMUNICATIONS, INC. to purchaser and/or end user for all damages including but not limited to compensatory, consequential and punitive damages, exceed the total amount paid to TC Communications, Inc. by purchaser for the goods from which the claim arose, in no event shall TC COMMUNICATIONS, INC. be responsible for indirect and consequential damages.
2. In no event shall liability attached to TC COMMUNICATIONS, INC. unless notice in writing is given to TC COMMUNICATIONS, INC. within ten days of the occurrence of the event giving rise to such claim.
3. TC COMMUNICATIONS, INC. shall not be responsible for delays or non-deliveries directly or indirectly resulting from or contributed to by foreign or domestic embargoes, seizure, fire, flood, explosion, strike, act of God, vandalism, insurrection, riot, war, or the adoption or enactment of any law, ordinances, regulation, or ruling or order or any other cause beyond the control of TC COMMUNICATIONS, INC.
4. TC COMMUNICATIONS, INC. shall not be responsible for loss or damage in transit and any claims for such loss or damage shall be filed by the purchaser with the carrier.

## B.1 Overview

This manual contains instructions which must be observed to ensure your own personal safety and to avoid damage to devices and machinery.

## B.2 Certified Usage

Please observe the following: The JumboSwitch may only be employed for the purposes described in the catalog and technical description, and only in conjunction with external devices and components recommended or approved by TC Communications. The product can only be operated correctly and safely if it is transported, stored, installed and assembled properly and correctly. Furthermore, it must be operated and serviced carefully.

### B.2.1 Qualification Requirements for Personnel

Qualified personnel as understood in this manual and the warning signs, are persons who are familiar with the setup, assembly, startup, and operation of this product and are appropriately qualified for their job. This includes, for example, those persons who have been trained or directed or authorized to switch on and off, to ground and to label power circuits and devices or systems in accordance with current safety engineering standards.

### B.2.2 National and International Safety Regulations

Ensure that the electrical installation meets local or nationally applicable safety regulations. The product can be used in living areas (living area, place of business, small business) and in industrial areas.

---

#### **CAUTION**



All LED components conform to the following standard; Light Emitting Diode - Class 1 Led Product.

---

**NOTE**

Appropriate testing has established that this device fulfills the requirements of a class A digital device in line with part 15 of the FCC regulations.

These requirements are designed to provide sufficient protection against interference where the device is being used in a business environment. The device creates and uses high frequencies and can radiate same, and if it is not installed and used in accordance with this operating manual, it can cause radio transmission interference. The use of this device in a living area can also cause interference, and in this case the user is obliged to cover the costs of removing the interference.

### B.2.3 Recycling

After usage, this product must be disposed of properly as electronic waste in accordance with the current disposal regulations of your county / state / country.

## B.3 Power Supply

This device is electrically operated. Adhere strictly to the safety requirements relating to voltages applied to the device as described in the *Specifications*, on page 1-6.

### B.3.0.1 General Safety Instructions

The TC 3848 is designed for operation with a safety extra-low voltage. It may only be connected to the supply voltage connections and to the signal contact with SELV circuits with the voltage restrictions in accordance with IEC/EN 60950-1. The supply voltage is electrically isolated from the housing.

- Use only undamaged systems! See *Installation*, on page 2-1.
- Relevant for North America: For Use in Class 2 Circuits. The subject unit is to be supplied by a Class 2 power source complying with the requirements of the National Electrical Code, table 11(b). If the power is redundant supplied (two individual power sources) the power sources together should comply with the requirements of the National Electrical Code, table 11 (b).
- Relevant for North America: Use 60/75°C or 75°C copper wire (CU) only.
- Relevant for North America for devices certified for hazardous locations: Peripheral equipment must be suitable for the location it is used in. Power, input and output (I/O) wiring must be in accordance with Class I, Division 2 wiring methods [Article 501-4(b) of the National Electrical Code, NFPA 70] and in accordance with the authority having jurisdiction.

- The device does not contain any service components. Internal fuses only trigger if there is a fault in the device. If the device is not functioning correctly, or if it is damaged, switch off the voltage supply and contact TC communications customer service.
- Only switch on the supply voltage to the device if the housing is closed, the terminal blocks are wired up correctly and the terminal blocks are connected to the correct type of voltage supply.

### **B.3.0.2 Grounding**

All TC Communications products are fully grounded and are in compliance accordance with all regulations and *Specifications*, on page 1-6.

### **B.3.0.3 Housing**

Only technicians authorized by TC Communications are permitted to open the housing and break the seal.

- Ensure that the electrical installation meets local or nationally applicable safety regulations.
- Never insert pointed objects (thin screwdrivers, wires, etc.) into the inside of the ventilation holes in the side of the housing! Failure to observe this point may result in injuries caused by electric shocks.

## **B.4 Environment**

"Industrial Hardened" and "Industrial Ethernet" describe communications products designed to operate in industrial process control environments or geographical locations where harsh conditions are common.

To meet this level of durability, "Industrial" grade (synonyms for "industrial" commonly include "rugged," "outdoor," "hardened," and "substation hardened") TC's communications products are manufactured with special components, connectors and circuitry. This ensures reliable operation in the event of wide temperature swings, electromagnetic interference (EMI), radio interference, vibrations, or moisture and humidity fluctuations. Conformal coating is optional.

TC Communications Industrial Grade products are designed to exceed pertinent industry specifications. For example, communications equipment used in power substations are subject to extremes of temperature and humidity, as well as electrical transients from high voltage switching.

These environmental conditions are described in industrial standard specifications IEC 61850-3 and IEEE 1613 for networking devices. Similarly, equipment used for traffic control applications are required to withstand roadside vibration in addition to high/low heat and humidity. Testing standards pertinent to traffic control are described in the environmental requirements of the NEMA TS-2 standard.

Every TC Communications product passes through "live operating temperature" testing (unlike randomly selected products for statistical sampling) before it is shipped. Each unit is connected to an operating BER tester to ensure error-free operation while the temperature chamber cycles from -40°C to 80°C during the 24 hour testing period.

- The installation location is to be selected so as to ensure compliance with the climatic limits listed in the Technical Data.
- Ensure the following criteria in site selection;
  - Room for adequate ventilation and cable routing.
  - Reserve space at least 0.5 m at the front and rear of the unit for human access, cables, and air flow.

---

**Important**

- Avoid locating it next to any equipment that may produce electrical interference or strong magnetic fields, such as elevator shafts or heavy duty power supplies.
  - As with any electronic equipment, keep the unit from excessive moisture, heat, vibration, and freezing temperatures.
-